



PUR360 CUSTOMER CHECKLIST

1

Identify and inform Pur360's technician of all contaminated areas.

2

Identify and inform Pur360's technician of all non-visible interior openings to outside.

3

All carpets and floors must be vacuumed and cleaned before and after the treatment.

4

Any damaged property should be repaired or replaced prior to treatment.

5

Repair all leaks and use dehumidifiers and fans to dry out any wet areas.

6

Remove HVAC filter and have new filter ready to install after treatment is complete.

7

Windows have been closed and locked. Remove all people, pets and plants from the premises.

8

All parties with keys/codes to premises have been notified NOT to enter premises.

9

All entrances have been locked after technician's setup is complete.