



| ELECTRICAL SYMBOL KEY | |
|-----------------------|---|
| LIGHT FIXTURES | |
| [Symbol] | RECESSED CAN LIGHT |
| [Symbol] | RECESSED CAN - EYEBALL |
| [Symbol] | CEILING SURFACE MOUNT LIGHT |
| [Symbol] | WALL SURFACE MOUNT LIGHT |
| [Symbol] | LIGHT w/ PULL CHAIN SWITCH |
| [Symbol] | WALL SCONCE |
| [Symbol] | FLUORESCENT FIXTURE (LENGTH FT/TUBE) |
| OUTLETS | |
| [Symbol] | DUPLEX OUTLET |
| [Symbol] | SPECIAL PURPOSE OUTLET (L.S. W.P. - G.P.T.) |
| [Symbol] | SWITCHED DUPLEX OUTLET |
| [Symbol] | RANGE/DRYER 220V OUTLET |
| [Symbol] | DIRECT WIRE CONNECTION |
| [Symbol] | TELEPHONE OUTLET |
| [Symbol] | CATV (TELEVISION) OUTLET |
| [Symbol] | THERMOSTAT |
| [Symbol] | UNDER-COUNTER OR CONCEALED OUTLETS |
| [Symbol] | CEILING MOUNTED DUP. OUTLET |
| SWITCHES | |
| [Symbol] | SINGLE POLE SWITCH |
| [Symbol] | THREE-WAY SWITCH |
| [Symbol] | FOUR-WAY SWITCH |
| [Symbol] | USER DEFINED SWITCH |
| MISC FIXTURES | |
| [Symbol] | EXHAUST FAN |
| [Symbol] | EXHAUST FAN/LIGHT |
| [Symbol] | EXHAUST FAN/LIGHT/HEAT |
| [Symbol] | SMOKE DETECTOR |
| [Symbol] | ELECTRIC WALL HEATER |
| [Symbol] | ELECTRICAL PANEL |
| [Symbol] | EMERGENCY LIGHTING |
| [Symbol] | EXIT SIGN |
| [Symbol] | BASEBOARD ELECTRICAL HEATER |

FIRST FLOOR ELECTRIC
SCALE: 1/8" = 1'-0"