



#### Southeast Environmental Microbiology Laboratories

440 Cobia Drive Ste. 1901 Katy, TX. 77494 Phone: (832) 437-2667

formation and data for <b>Asbestos &amp; Mold</b> cy. The following reports are contained w		<del>_</del>
Surface/Bulk Report Spore Trap Report		Andersen Fungal Report Quantitative Fungal Report
Lab Manager Review: Magzou	b Isma	<i>AÍL</i> Date: 11/05/2021

Thank you for using SEEML laboratories. We strive to provide superior quality and service. SEEML laboratories are accredited through AIHA-LAP, LLC (EMLAP #232339) for the analysis of Spore Traps and Surface/Bulk Samples and licensed by the Texas Department of Licensing and Regulation (LAB1016).

The data within this report is reliable to three significant figures. The third significant figure is technically unjustified. In this instance, the third figure is reported as an estimate to facilitate the interpretation by the customer.

#### Confidentiality Notice:

The document(s) contained herein are confidential and privileged information, intended for the exclusive use of the individual or entity named above. If the reader of this message is not the intended recipient, or the employee or agent responsible for delivering it to the intended recipient, you are hereby notified that any dissemination, distribution or copying of the document(s) is strictly prohibited. If you have received this document in error, please immediately notify us by telephone to arrange for its return. Thank you.

#### Guidelines for Interpretation:

No accepted quantitative regulatory standards currently exist by which to assess the health risks related to mold and bacterial exposure. Molds and bacteria have been associated with a variety of health effects and sensitivity varies from person to person.

Several organizations, including: the American Conference of Government Industrial Hygienists (ACGIH); the American Industrial Hygiene Association (AIHA); the Indoor Air Quality Association (IAQA); the United States Environmental Protection Agency (USEPA); the Centers for Disease Control (CDC), as well as the California Department of Health Services (CADHS), have all published guidelines for assessment and interpretation of mold resulting from water intrusion in buildings.

Interpretation of the data and information within this document is left to the company, consultant, and/or persons who conducted the fieldwork.

Asbestos & Mold Services	Date Sampled:
62 Regency Point	Date Received: 11/05/2021
Montgomery, TX 77356	Date Analyzed: 11/05/2021
713-890-2003	Date Reported: 11/05/2021
	Date Revised:
	Project Name: 9733 Meador Rd
	Project Address:
	Project City, State, ZIP:
	SEEML Reference #: H-211105023

TEST METHOD: DIDECT MICROSCODY EYAMINATION SEEML SOR 7

Client Sample ID		10			11			12		
Location	Brick Room			Sons Room			South Wall Office			
Comment/Notes										
Lab Sample ID	H-	211105023-1	I11	H-	211105023-1	12	H-	211105023-1	13	
Detection Limit (spores/m³)		13			13			67		
Hyphal Fragments	1	13		1	13					
Pollen	1	13								
Spore Trap Used		Allergenco			Allergenco			Allergenco		
-	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%	
Alternaria	10.11 01.1		,,,		Sp 5: 55,	,,,		0,00,00,		
Ascospores										
Basidiospores				4	52	7				
Bipolaris/Drechslera						•				
Chaetomium										
Cladosporium	8	104	7							
Curvularia										
Epicoccum										
Cercospora		1								
Fusarium										
Memnoniella										
Nigrospora	1	13	<1							
Penicillium/Aspergillus	100	1300	89	52	676	91	2120	142000	100	
Polythrincium										
Rusts										
Smuts/Periconia/Myxomy	2	26	2	1	13	2				
Spegazzinia										
Stachybotrys										
Stemphylium										
Tetraploa										
Torula										
Ulocladium										
Colorless/Other Brown*										
Oidium										
Zygomycetes										
Pithomyces	1	13	<1							
Background debris (1-5)**	2			2			4			
Sample Volume(liters)	75			75			15			
TOTAL SPORES/M <sup>3</sup>	112	1460		57	741		2120	142000		

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

The analytical sensitivity is the spores/m<sup>3</sup> divided by the raw count, expressed in spores/m<sup>3</sup>. The limit of detection is the analytical sensitivity (in spores/m<sup>3</sup>) multiplied by the sample volume (in liters) divided by 1000 liters.

Disclaimer: The sample results are determined by the sample volume, which is privided by the customer.

This report relates only to the samples tested as they were received.

Katy, TX. 77494

Respectfully submitted, SEEML

Phone: (832) 437-2667

440 Cobia Drive Ste. 1901

<sup>\*</sup>Colorless,other Brown are spores without a distinctive morphology on spore traps and non-viable surface samples.

<sup>\*\*</sup>Background debris is the amount of particulate matter present on the slide and is graded from 1-5 with 1 = very light, 2= Light, 3 = Medium, 4 = Heavy, 5 = Very Heavy. The higher the rating the more likelihood spores may be underestimated. A rating of 5 should be interpreted as minimal counts and may actually be higher than reported.

Asbestos & Mold Services	Date Sampled:
62 Regency Point	Date Received: 11/05/2021
Montgomery, TX 77356	Date Analyzed: 11/05/2021
713-890-2003	Date Reported: 11/05/2021
	Date Revised:
	Project Name: 9733 Meador Rd
	Project Address:
	Project City, State, ZIP:
	SEEML Reference # : H-211105023

TEST METHOD: DIRECT MICROSCOPY EXAMINATION SEEML SOP 7

Client Sample ID	13			14		15			
Location	East Divider Dinning To Office		Sc	South Dinning Wall			Living Room East Wall Divide To Dining		
Comment/Notes									
Lab Sample ID	H-	211105023-	114	H-	211105023-1	15	H-	211105023-1	116
Detection Limit (spores/m³)		67			67			67	
Hyphal Fragments	3	201		11	737				
Pollen							1	67	
Spore Trap Used		Allergenco			Allergenco			Allergenco	
	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%
Alternaria									
Ascospores									
Basidiospores	12	804	<1						
Bipolaris/Drechslera							1	67	<1
Chaetomium	6	402	<1					1	•
Cladosporium	,								
Curvularia									
Epicoccum							1	67	<1
Cercospora									
Fusarium									
Memnoniella									
Nigrospora									
Penicillium/Aspergillus	2160	145000	99	10080	675000	100	5760	386000	100
Polythrincium									
Rusts									
Smuts/Periconia/Myxomy	1	67	<1				2	134	<1
Spegazzinia									
Stachybotrys									
Stemphylium									
Tetraploa									
Torula									
Ulocladium									
Colorless/Other Brown*	1	67	<1				4	268	<1
Oidium									
Zygomycetes									
Pithomyces							1	67	<1
Background debris (1-5)**	5			5			5		
Sample Volume(liters)	15			15			15		
TOTAL SPORES/M <sup>3</sup>	2180	146000		10080	675000		5769	387000	
Revisions:				-	· · · · · · · · · · · · · · · · · · ·		-		

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

The analytical sensitivity is the spores/m<sup>3</sup> divided by the raw count, expressed in spores/m<sup>3</sup>. The limit of detection is the analytical sensitivity (in spores/m<sup>3</sup>) multiplied by the sample volume (in liters) divided by 1000 liters.

Disclaimer: The sample results are determined by the sample volume, which is privided by the customer.

This report relates only to the samples tested as they were received.

Katy, TX. 77494

Respectfully submitted, SEEML

Phone: (832) 437-2667

440 Cobia Drive Ste. 1901

<sup>\*</sup>Colorless,other Brown are spores without a distinctive morphology on spore traps and non-viable surface samples.

<sup>\*\*</sup>Background debris is the amount of particulate matter present on the slide and is graded from 1-5 with 1 = very light, 2 = Light, 3 = Medium, 4 = Heavy, 5 = Very Heavy. The higher the rating the more likelihood spores may be underestimated. A rating of 5 should be interpreted as minimal counts and may actually be higher than reported.

Asbestos & Mold Services	Date Sampled:				
<b>62 Regency Point</b> Date Received: 11/05/2021					
Montgomery, TX 77356	Date Analyzed: 11/05/2021				
713-890-2003	Date Reported: 11/05/2021				
	Date Revised:				
	Project Name: 9733 Meador Rd				
	Project Address:				
	Project City, State, ZIP:				
	SEEMI Reference # : H-211105023				

TEST METHOD: DIRECT MICROSCOPY EXAMINATION SEEML SOP 7

Client Sample ID	MICROSCOPY EXAMINATION SEE				17		18		
Location	Brick Room South Wall Adj Kitchen			Sons Room West Wall			Sons Room East Wall		
Comment/Notes									
Lab Sample ID	H-	211105023-	117	H-	211105023-1	18	H-:	211105023-1	19
Detection Limit (spores/m³)		67			67			67	
Hyphal Fragments	6	402		8	536		5	335	
Pollen									
Spore Trap Used		Allergenco			Allergenco			Allergenco	
	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%
Alternaria	iaw ot.	орогооли	,,,	1411 01.	000000,111	7,0	i aw ou	operee/111	70
Ascospores				4	268	<1			
Basidiospores	8	536	<1	•	200			1	
Bipolaris/Drechslera		555							
Chaetomium	3	201	<1	16	1070	<1			
Cladosporium	28	1880	<1	52	3480	<1	32	2140	2
Curvularia	20	1000		4	268	<1	02	2110	
Epicoccum				<u>'</u>	200				
Cercospora									
Fusarium									
Memnoniella									
Nigrospora									
Penicillium/Aspergillus	11760	788000	100	10080	675000	99	1588	106000	97
Polythrincium									
Rusts									
Smuts/Periconia/Myxomy	1	67	<1	4	268	<1	7	469	<1
Spegazzinia									
Stachybotrys							6	402	<1
Stemphylium									
Tetraploa									
Torula									
Ulocladium									
Colorless/Other Brown*	6	402	<1		1				
Oidium									
Zygomycetes									
Pithomyces									
Background debris (1-5)**	5			5			4		
Sample Volume(liters)	15			15			15		
TOTAL SPORES/M <sup>3</sup>	11806	791000		10160	680000		1633	109000	
Revisions:		•					•		

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

The analytical sensitivity is the spores/m<sup>3</sup> divided by the raw count, expressed in spores/m<sup>3</sup>. The limit of detection is the analytical sensitivity (in spores/m<sup>3</sup>) multiplied by the sample volume (in liters) divided by 1000 liters.

Disclaimer: The sample results are determined by the sample volume, which is privided by the customer.

This report relates only to the samples tested as they were received.

Katy, TX. 77494

Phone: (832) 437-2667

Respectfully submitted, SEEML

440 Cobia Drive Ste. 1901

<sup>\*</sup>Colorless,other Brown are spores without a distinctive morphology on spore traps and non-viable surface samples.

<sup>\*\*</sup>Background debris is the amount of particulate matter present on the slide and is graded from 1-5 with 1 = very light, 2= Light, 3 = Medium, 4 = Heavy, 5 = Very Heavy. The higher the rating the more likelihood spores may be underestimated. A rating of 5 should be interpreted as minimal counts and may actually be higher than reported.

Asbestos & Mold Services	Date Sampled:
62 Regency Point	Date Received: 11/05/2021
Montgomery, TX 77356	Date Analyzed: 11/05/2021
713-890-2003	Date Reported: 11/05/2021
	Date Revised:
	Project Name: 9733 Meador Rd
	Project Address:
	Project City, State, ZIP:
	SEEML Reference # : H-211105023

TEST METHOD: DIDECT MICROSCODY EYAMINATION SEEML SOR 7

Client Sample ID	19		20			21			
Location	Sons Room North Wall		Master (	Master Closet Behind Chimney			Garage Apt East Wall		
Comment/Notes									
Lab Sample ID	H-	211105023-1	120	H-	211105023-1	21	H-	211105023-1	22
Detection Limit (spores/m³)		67			67			67	
Hyphal Fragments	3	201							
Pollen									
Spore Trap Used		Allergenco			Allergenco			Allergenco	
<u> </u>	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%	raw ct.	spores/m <sup>3</sup>	%
Alternaria	raw ot.	эрогсэ/пт	70	Taw ot.	эрогозин	70	Taw ot.	эрогоз/пп	70
Ascospores									
Basidiospores				4	268	2			
Bipolaris/Drechslera				4	200				
Chaetomium									
Cladosporium				4	268	2			
Curvularia	4	268	<1	4	200				
Epicoccum	4	200							
Cercospora Fusarium									
Memnoniella									
							2	404	
Nigrospora	40700	2000000	400	000	45000	00	1852	134 124000	<1 100
Penicillium/Aspergillus	42720	2860000	100	236	15800	96	1852	124000	100
Polythrincium									
Rusts									
Smuts/Periconia/Myxomy									
Spegazzinia									
Stachybotrys									
Stemphylium									
Tetraploa									
Torula									
Ulocladium									
Colorless/Other Brown*				1	67	<1			
Oidium									
Zygomycetes									
Pithomyces									
Background debris (1-5)**	5			3			4		
Sample Volume(liters)	15			15			15		
TOTAL SPORES/M <sup>3</sup>	42724	2860000		245	16400		1854	124000	

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

The analytical sensitivity is the spores/m<sup>3</sup> divided by the raw count, expressed in spores/m<sup>3</sup>. The limit of detection is the analytical sensitivity (in spores/m<sup>3</sup>) multiplied by the sample volume (in liters) divided by 1000 liters.

Form 18.0 Rev 4 03/01/19

Disclaimer: The sample results are determined by the sample volume, which is privided by the customer.

This report relates only to the samples tested as they were received.

Phone: (832) 437-2667

Katy, TX. 77494

440 Cobia Drive Ste. 1901

Respectfully submitted, SEEML

Magzoub Ismail

Magzoub Ismail, Approved Laboratory Signatory

AIHA-LAP, LLC EMLAP #232339

Texas Lic: LAB1016

<sup>\*</sup>Colorless,other Brown are spores without a distinctive morphology on spore traps and non-viable surface samples.

<sup>\*\*</sup>Background debris is the amount of particulate matter present on the slide and is graded from 1-5 with 1 = very light, 2= Light, 3 = Medium, 4 = Heavy, 5 = Very Heavy. The higher the rating the more likelihood spores may be underestimated. A rating of 5 should be interpreted as minimal counts and may actually be higher than reported.

Asbestos & Mold Services	Date Sampled:
62 Regency Point	Date Received: 11/05/2021
Montgomery, TX 77356	Date Analyzed: 11/05/2021
713-890-2003	Date Reported: 11/05/2021
	Date Revised:
	Project Name: 9733 Meador Rd
	Project Address:
	Project City, State, ZIP:
	SEFML Reference # : H-211105023

<b>TEST METHOD: DIRECT M</b>	MICROSCO	PY EXAMIN	IATION SE	EML SOP 7	1				
Client Sample ID		22							
Location	L/R Bedhind Laundry								
Comment/Notes									
Lab Sample ID	H-	211105023-1	123						
Detection Limit (spores/m <sup>3</sup> )		67			67			67	
Hyphal Fragments									
Pollen	4	268							
Spore Trap Used		Allergenco			•	•		•	
	raw ct.	spores/m <sup>3</sup>	%						
Alternaria	1	67	<1						
Ascospores	8	536	<1						
Basidiospores	48	3220	<1						
Bipolaris/Drechslera	1	67	<1						
Chaetomium	1	67	<1						
Cladosporium	88	5900	<1						
Curvularia	5	335	<1						
Epicoccum									
Cercospora									
Fusarium									
Memnoniella									
Nigrospora	1	67	<1						
Penicillium/Aspergillus	9120	611000	98						
Polythrincium									
Rusts									
Smuts/Periconia/Myxomy	3	201	<1						
Spegazzinia									
Stachybotrys									
Stemphylium									
Tetraploa									
Torula									
Ulocladium									
Colorless/Other Brown*	2	134	<1						
Oidium									
Zygomycetes									
Pithomyces									
Background debris (1-5)**	4								
Sample Volume(liters)	15			15			15		
TOTAL SPORES/M <sup>3</sup>	9278	622000							
Revisions:									

#### Comments

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

The analytical sensitivity is the spores/m<sup>3</sup> divided by the raw count, expressed in spores/m<sup>3</sup>. The limit of detection is the analytical sensitivity (in spores/m<sup>3</sup>) multiplied by the sample volume (in liters) divided by 1000 liters.

Disclaimer: The sample results are determined by the sample volume, which is privided by the customer.

This report relates only to the samples tested as they were received.

Katy, TX. 77494 Phone: (832) 437-2667

440 Cobia Drive Ste. 1901

Respectfully submitted, SEEML

<sup>\*</sup>Colorless,other Brown are spores without a distinctive morphology on spore traps and non-viable surface samples.

<sup>\*\*</sup>Background debris is the amount of particulate matter present on the slide and is graded from 1-5 with 1 = very light, 2= Light, 3 = Medium, 4 = Heavy, 5 = Very Heavy. The higher the rating the more likelihood spores may be underestimated. A rating of 5 should be interpreted as minimal counts and may actually be higher than reported.

## **Fungal Descriptions**

#### Alternaria sp.

Aw - 0.89. Conidia dimensions: 18-83 x 7-18 microns. A very common allergen with an IgE mediated response. It is often found in carpets, textiles and on horizontal surfaces in building interiors. Often found on window frames. Outdoors it may be isolated from samples of soil, seeds and plants. It is commonly found in outdoor samples. The large spore size, 20 - 200 microns in length and 7 - 18 microns in sizes, suggests that the spores from these fungi will be deposited in the nose, mouth and upper respiratory tract. It may be related to bakers' asthma. It has been associated with hypersensitivity pneumonitis. The species *Alternaria alternata* is capable of producing tenuazonic acid and other toxic metabolites that may be associated with disease in humans or animals. Common cause of extrinsic asthma (immediate-type hypersensitivity: type I). Acute symptoms include edema and bronchiospasms; chronic cases may develop pulmonary emphysema.

#### **Ascospore**

A spore borne in a special cell called an ascus. Spores of this type are reported to be allergenic.

All ascomycetes, members of a group of fungi called Ascomycotina, have this type of spore. The minute black dots on rotting wood and leaves or the little cups on lichens are examples of ascomycetes; another is the "truffle" mushroom.

## Aspergillus/Penicillium

These are two of the most commonly found allergenic fungi in problem buildings. *Aspergillus* comes in many varieties (species). Many of the varieties produce toxic substances. It may be associated with symptoms such as sinusitis, allergic bronchiopulmonary aspergillosis, and other allergic symptoms.

*Penicillium* is a variety of mold that is very common indoors and is found in increased numbers in problem buildings. It also has many varieties, some of which produce toxic substances. The symptoms are allergic reactions, mucous membrane irritation, headaches, vomiting, and diarrhea.

Because the spores of *Aspergillus* and *Penicillium* are very similar, they are not differentiated by microscopic analysis and are reported together.

#### Aspergillus sp.

Aw 0.75 - 0.82. Reported to be allergenic. Members of this genus are reported to cause ear infections. Many species produce mycotoxins that may be associated with disease in humans and other animals. Toxin production is dependent on the species or a strain within a species and on the food source for the fungus. Some of these toxins have been found to be carcinogenic in animal species. Several toxins are considered potential human carcinogens. Common cause of extrinsic asthma (immediate-type hypersensitivity: type I). Acute symptoms include edema and bronchiospasms; chronic cases may develop pulmonary emphysema; may also be associated with sinusitis, allergic bronchiopulmonary aspergillosis, and other allergic symptoms.

#### **Basidiospore**

Spore from basidiomycetes. Many varieties are reported to be allergenic.

#### Bipolaris sp.

A fungus with large spores that could be expected to be deposited in the upper respiratory tract. This fungus can produce the mycotoxin - sterigmatocystin, which has been shown to produce liver and kidney damage when ingested by laboratory animals.

#### Botrytis sp.

Aw 0.93. Conidia dimensions: 7-14 x 5-9 microns. It is parasitic on plants and soft fruits. Found in soil and on house plants and vegetables, it is also known as "gray mold". It causes leaf rot on grapes, strawberries, lettuce, etc. It is a well-known allergen, producing asthma type symptoms in greenhouse workers and "wine grower's lung".

#### Cercaspora

Common outdoors in agricultural areas, especially during harvest. Parasite of higher plants, causing leaf spot. Commonly found as parasites on higher plants.

#### Chaetomium sp.

large ascomycetous fungus producing perithecia. It is found on a variety of substrates containing cellulose, including paper and plant compost. It has been found on paper in sheetrock. It can produce an *Acremonium*-like state on fungal media. Varieties are considered allergenic and have been associated with peritonitis, cutaneous lesions, and system mycosis.

#### Cladosporium sp.

Aw 0.88; Aw 0.84. Most commonly identified outdoor fungus. The outdoor numbers are reduced in the winter. The numbers are often high in the summer. Often found indoors in numbers less than outdoor numbers. It is a common allergen. Indoor *Cladosporium* sp. may be different than the species identified outdoors. It is commonly found on the surface of fiberglass duct liners in the interior of supply ducts. A wide variety of plants are food sources for this fungus. It is found on dead plants, woody plants, food, straw, soil, paint, and textiles. Produces greater than 10 antigens. Antigens in commercial extracts are of variable quality and may degrade within weeks of preparation. Common cause of extrinsic asthma (immediate-type hypersensitivity: type I). Acute symptoms include skin lesions, eye ulceration, mycosis (including onychomycosis, an infection of the nails of the feet or hands) edema and bronchiospasms; chronic cases may develop pulmonary emphysema.

#### Curvularia sp.

Reported to be allergenic and has been associated with allergic fungal sinusitis. It may cause corneal infections, mycetoma, and infections in immune compromised hosts.

#### Dreschlera sp.

Conidia dimensions: 40-120 x 17-28 microns. Found on grasses, grains and decaying food. It can occasionally cause a corneal infection of the eye.

#### Epicoccum sp.

Conidia dimensions: 15-25 microns. A common allergen. It is found in plants, soil, grains, textiles and paper products.

#### Fusarium sp.

Aw 0.90. A common soil fungus. It is found on a wide range of plants. It is often found in humidifiers. Several species in this genus can produce potent trichothecene toxins. The trichothecene (scirpene) toxin targets the following systems: circulatory, alimentary, skin, and nervous. Produces vomitoxin on grains during unusually damp growing conditions. Symptoms may occur either through ingestion of contaminated grains or possibly inhalation of spores. The genera can produce hemorrhagic syndrome in humans (alimentary toxic aleukia). This is characterized by nausea, vomiting, diarrhea, dermatitis, and extensive internal bleeding. Reported to be allergenic. Frequently involved in eye, skin, and nail infections.

#### **Myxomycetes**

Members of a group of fungi that is included in the category of "slime molds". They're occasionally found indoors, but mainly reside in forested regions on decaying logs, stumps, and dead leaves. Myxomycetes display characteristics of fungi *and* protozoans. In favorable (wet) conditions they exhibit motile, amoeba-like cells, usually bounded only by a plasma membrane, that are variable in size and form. During dry spells, they form a resting body (sclerotium) with dry, airborne spores. These fungi are not known to produce toxins, but can cause hay fever and asthma.

#### Memnoniella

Contaminant, found most often with Stachybotrys on wet cellulose. Forms in chains, but it are very similar to Stachybotrys and sometimes is considered to be in the Stachybotrys family. Certain species do produce toxins very similar to the ones produced by Stachybotrys chartarum and many consider the IAQ importance of Memnoniella to be on par with Stachybotrys. Allergenic and infectious properties are not well studied.

#### Nigrospora sp.

Commonly found in warm climates, this mold may be responsible for allergic reactions such as hay fever and asthma. It is found on decaying plant material and in the soil. It is not often found indoors.

#### Oidium sp.

The asexual phase of *Erysiphe* sp. It is a plant pathogen causing powdery mildews. It is very common on the leaves stems, and flowers of plants. The health effects and allergenicity have not been studied. It does not grow on non-living surfaces such as wood or drywall.

#### Penicillium sp.

Aw 0.78 - 0.88. A wide number of organisms have been placed in this genus. Identification to species is difficult. Often found in aerosol samples. Commonly found in soil, food, cellulose and grains. It is also found in paint and compost piles. It may cause hypersensitivity pneumonitis, allergic alveolitis in susceptible individuals. It is reported to be allergenic (skin). It is commonly found in carpet, wallpaper, and in interior fiberglass duct insulation. Some species can produce mycotoxins. Common cause of extrinsic asthma (immediate-type hypersensitivity: type I). Acute symptoms include edema and bronchiospasms; chronic cases may develop pulmonary emphysema. It may also cause headaches, vomiting, and diarrhea.

#### Periconia sp.

found in soil, blackened and dead herbaceous stems leaf spots, grasses, rushes, and sedges. Almost always associated with other fungi. Rarely found growing indoors. Reportedly associated with a rare case of mycotic keratitis.

## Pithomyces sp.

A common mold found on dead leaves, plants, soil and especially grasses. Causes facial eczema in ruminants. It exhibits distinctive multi-celled brown conidia. It is not know to be a human allergen or pathogen. It is rarely found indoors, although it can grow on paper.

#### **Rusts/Smuts**

These fungi are associated with plant diseases. In the classification scheme of the fungi, the smuts have much in common with the rusts, and they are frequently discussed together. Both groups produce wind-borne, resistant teliospores that serve as the basis for their classification and their means of spread. Rusts usually attack vegetative regions (i.e., leaves and stems) of plants; smuts usually are associated with the reproductive structures (seeds). They can cause hay fever and asthma.

#### **Spegazzinia**

Spegazzinia species comprise a very small proportion of the fungal biota. This genus is somewhat related to other lobed or ornamented genera such as Candelabrum. No information is available regarding health effects or toxicity. Allergenicity has not been studied. Usually identified on spore trap samples where it is seen every few weeks. (Spores have very distinctive morphology.) May also be found in air by culturable (Andersen) samples if a long enough incubation period is provided so that sporulation occurs. Our laboratory has never found this organism growing on indoor environmental surfaces. Natural habitat includes soil and many kinds of trees and plants.

#### Stachybotrys sp.

Aw - 0.94, optimum Aw ->0.98. Several strains of this fungus (*S. atra, S. chartarum* and *S. alternans* are synonymous) may produce a trichothecene mycotoxin- Satratoxin H - which is poisonous by inhalation. The toxins are present on the fungal spores. This is a slow growing fungus on media. It does not compete well with other rapidly growing fungi. The dark colored fungus grows on building material with high cellulose content and low nitrogen content. Areas with a relative humidity above 55%, and are subject to temperature fluctuations, are ideal for toxin production.

Individuals with chronic exposure to the toxin produced by this fungus reported cold and flu symptoms, sore throats, diarrhea, headaches, fatigue, dermatitis, intermittent local hair loss and generalized malaise. Other symptoms include coughs, rhinitis, nosebleed, a burning sensation in the nasal passages, throat, and lungs, and fever. The toxins produced by this fungus will suppress the immune system affecting the lymphoid tissue and the bone marrow. Animals injected with the toxin from this fungus exhibited the following symptoms: necrosis and hemorrhage within the brain, thymus, spleen, intestine, lung, heart, lymph node, liver, and kidney. Affects by absorption of the toxin in the human lung are known as pneumomycosis.

This organism is rarely found in outdoor samples. It is usually difficult to find in indoor air samples unless it is physically disturbed (or possibly -this is speculation- a drop in the relative humidity). The spores are in a gelatinous mass. Appropriate media for the growth of this organism will have high cellulose content and low nitrogen content. The spores will die readily after release. The dead spores are still allergenic and toxigenic. Percutaneous absorption has caused mild symptoms.

## Stemphylium sp.

Reported to be allergenic. Isolated from dead plants and cellulose materials.

#### Torula sp.

Found outdoors in air, soil, on dead vegetation, wood, and grasses. Also found indoors on cellulose materials. Reported to be allergenic and may cause hay fever and asthma.

#### **Tetraploa**

Tetraploa species comprise a very small proportion of the fungal biota. This genus is somewhat related to Triposporium and Diplocladiella. The only reported human infections are two cases of keratitis (1970, 1980) and one case of subcutaneous infection of the knee (1990). No information is available regarding other health effects or toxicity. Allergenicity has not been studied. Usually identified on spore trap samples where it is seen every few weeks. (Spores have very distinctive morphology.) Our laboratory has never found this organism growing on indoor environmental surfaces. Natural habitat includes leaf bases and stems just above the soil on many kinds of plants and trees.

#### Ulocladium sp.

Aw 0.89. Isolated from dead plants and cellulose materials. Found on textiles.

#### **Zygomycetes**

Zygomycetes are one of the four major groups of fungi, the others being the Oomycetes, the Ascomycetes, and the Basidiomycetes. Zygomycetes are common, fast growing, and often overgrow and/or inhibit other fungi nearby. Rhizopus and Mucor are two of the most common Zygomycetes seen in the indoor environment. However, others are seen as well, including Syncephalastrum, Circinella, Mortierella, Mycotypha, Cunninghamella, and Choanephora. For further information, please see descriptions of these individual genera.

# The following table lists mycotoxins that are produced by certain types of fungi:

Fungi	Mycotoxin
Acremonium crotocinigenum	Crotocin
Aspergillus favus	Alfatoxin B, cyclopiazonic acid
Aspergillus fumigatus	Fumagilin, gliotoxin
Aspergillus carneus	Critrinin
Aspergillus clavatus	Cytochalasin, patulin
Aspergillus Parasiticus	Alfatoxin B
Aspergillus nomius	Alfatoxin B
Aspergillus niger	Ochratoxin A, malformin, oxalicacid
Acremonium crotocinigenum	Crotocin
Aspergillus nidulans	Sterigmatocystin
Aspergillus ochraceus	Ochratoxin A, penicillic acid
Aspergillus versicolor	Sterigmatocystin, 5 ethoxysterigmatocystin
	Ausdiol, austamide,
Aspergillus ustus	austocystin,brevianamide
Aspergillus terreus	Citreoviridin
A14	Alternariol, altertoxin, altenuene, altenusin,
Alternaria	tenuazonic acid
Arthrinium	Nitropropionic acid
D' 1 '	Cytochalasin, sporidesmin,
Bioploaris	sterigmatocystin
Chaetomium	Chaetoglobosin A,B,C. Sterigmatocystin
Cladosporium	Cladosporic acid
Clavipes purpurea	Ergotism
Cylindrocorpon	Trichothecene
Diplodia	Diplodiatoxin
Fusarium	Trichothecene, zearalenone
Fusarium moniliforme	Fumonisins
Emericella nidulans	Sterigmatocystin
Gliocladium	Gliotoxin
	Griseofulvin, dechlorogriseofulvin, epi-
Memnoniella	decholorgriseofulvin, trichodermin,
	trichodermol
Myrothecium	Trichothecene
Paecilomyces	Patulin, viriditoxin
Penicillium aurantiocandidum	Penicillic acid
Penicillium aurantiogriseum	Penicillic acid
Penicillium brasilanum	Penicillic acid
Penicillium brevicompactum	Mycophenolic acid
Penicillium camemberti	Cyclopiazonic acid
Penicillium carneum	Mycophenolic acid, Roquefortine C
Penicillium crateriforme	Rubratoxin

Penicillium citrinum	Citrinin
Penicillium commune	Cyclopiazonic acid
Penicillium crustosum	Roquefortine C
Penicillium chrysogenum	Roquefortine C
Penicillium discolor	Chaetoglobosin C
Penicillium expansum	Citrinin, Roquefortine C
Penicillium griseofulvum	Roquefortine C, cyclopiazonic acid, griseofulvin
Penicillium hirsutum	Roquefortine C
Penicillium hordei	Roquefortine C
Penicillium nordicum	Ochratoxin A
Penicillium paneum	Roquefortine C
Penicillium palitans	Cyclopiazonic acid
Penicillium polonicum	Penicillic acid
Penicillum roqueforti	Roquefortine C, Mycophenolic acid
Penicillium veridicatum	Penicillic acid
Penicillium verrucosum	Citrinin, ochratoxin A
Penicillium/ Aspergillus	Patulin
Penicillium/ Aspergillus/Alternaria	Glitoxin
Phomopsis	Macrocyclic trichothecenes
Phoma	Brefeldin, cytochalasin, secalonic acid, tenuazonic acid
Pithomyces	Sporidesmin
Rhizoctonia	Slaframine
Rhizopus	Rhizonin
Sclerotinia	Furanocoumarins
Stachybotrys chartarum	Iso-satratoxin F, roridin E, L-2, satratoxin G & H, trichodermin, trichodermol, trichothecene
Torula	Cytotoxins
Trichoderma	Trichodermin, trichodermol, gliotoxin
Trichothecium	Trichothecene
Wallemia	Walleminol
Zygosporium	Cytochalasin

#### **General terms**

#### **Allergen**

An allergen is a substance that elicits an IgE <u>antibody</u> response and is responsible for producing allergic reactions. Chemicals are released when IgE on certain cells come into contact with an allergen. These chemicals can cause injury to surrounding tissue - the visible signs of an allergy. Only a few fungal allergens have been characterized but all fungi are thought to be potentially allergenic. Fungal allergens are proteins found in either the mycelium or spores

#### "Black mold"

The poorly defined term? Black mold? Or? Toxic black mold? Has usually been associated with the mold *Stachybotrys chartarum*. While there are only a few molds that are truly black, there are many that can appear black. Not all molds that appear to be black are *Stachybotrys*.

#### **Fungi**

Fungi are neither animals nor plants and are classified in a kingdom of their own? The Kingdom of Fungi. Fungi include a very large group of organisms, including molds, yeasts, mushrooms and puffballs. There are >100,000 accepted fungal species but current estimates range to 1.5 million species. Mycologists (people who study fungi) have grouped fungi into four large groups according to their method of reproduction.

#### **Hidden mold**

This refers to visible mold growth on building structures that is not easily seen, including the areas above drop ceilings, within a wall cavity (the space between the inner and outer structure of a wall), inside air handlers, or within the ducting of a heating/ventilation system.

#### **Microbial Volatile Organic Compounds (MVOCs)**

Fungi produce chemicals as a result of their metabolism. Some of these chemicals, MVOCs, are responsible for the characteristic moldy, musty, or earthy smell of fungi, whether mushrooms or molds. Some MVOCs are considered offensive or annoying. Specific MVOCs are thought to be characteristic of wood rot and mold growth on building materials. The human nose is very sensitive to mold odors and sometimes more so than current analytical instruments.

#### Mold

Molds are a group of organisms that belong to the Kingdom of Fungi (see Fungi). Even though the terms mold and fungi had been commonly referred to interchangeably, all molds are fungi, but not all fungi are molds.

#### **Mycotoxin**

Mycotoxins are compounds produced by some fungi that are toxic to humans or animals. By convention, the term? Mycotoxin? Excludes mushroom toxins. Fungi that produce mycotoxins are called "toxigenic fungi.

#### **Spore**

General Term for a reproductive structure in fungi, bacteria and some plants. In fungi, the spore is the structure which may be used for dissemination and may be resistant to adverse environmental conditions.

#### **Toxic mold**

The term? Toxic mold" has no scientific meaning since the mold itself is not toxic. The metabolic byproducts of some molds may be toxic (see mycotoxin).

## Hypha (plural, hyphae)

An individual fungal thread or filament of connected cells; the thread that represents the individual parts of the fungal body.